

**techflo**  
qt

## **Installation, Operation & Maintenance Instructions**

**Please leave this instruction booklet with the owner as it contains important guarantee, maintenance and safety information**



**Read this manual carefully before commencing installation.**

This manual covers the following products:

**U2.3 bar Twin**

Pt. No. 49080

**U2.3 bar Single**

Pt. No. 49082

**U3.3 bar Twin**

Pt. No. 49081

**U3.3 bar Single**

Pt. No. 49083

**FOR POSITIVE OR NEGATIVE HEAD APPLICATIONS**



**PRODUCT DESCRIPTION**

Electric motor driven single or twin ended centrifugal pump, complete with an automatic control system, consisting of flow switches and electronic controls.

**APPLICATION**

Techflo qt pumps are suitable for positive or negative head installation conditions. The pumps are designed for whole house pressure boosting applications in vented stored water systems. Inlet pressures to the pump and ambient temperatures must not exceed the values given in the technical specifications.



- **This pump set must not be used for any other application without the written consent of Stuart Turner Limited and in particular, MUST NOT be connected directly to the mains water supply.**
- **This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.**
- **Children should be supervised to ensure that they do not play with the appliance.**

**Please read installation details carefully as they are intended to ensure this product provides long, trouble free service. Failure to install the unit in accordance with the installation instructions will lead to invalidation of the warranty.**


**STORAGE**

If this product is not to be installed immediately on receipt, ensure that it is stored in a dry, frost and vibration free location in its original packaging.

**CONTENTS**

	Page
Checklist . . . . .	3
Pre-Installation . . . . .	4
Important Facts - read before commencing installation . . . . .	5
Location . . . . .	6
Pump Connections . . . . .	9
Electrical Installation . . . . .	11
Commissioning . . . . .	13
Maintenance . . . . .	14
Technical Specification . . . . .	16
Trouble Shooting . . . . .	18
Guarantee . . . . .	20

# CHECKLIST



Item	Description	Qty	Item	Description	Qty
(A)	Pump	1	(C)	Outlet hose only	2 (1)
(B)	Inlet hose with isolating valve	2 (1)			



Your product may vary slightly from the picture above.  
 The quantities shown above are for twin pumps, (single pumps are shown in brackets).

## PRE-INSTALLATION ASSEMBLY

The pump as supplied requires some installer assembly.

1. Remove the two red transportation caps by unscrewing; these can be discarded (Fig. 2).
2. Check to ensure the 'O'-rings are in position inside the large plastic nut on the top of the pump.
3. Lift the 'H' frame assembly and gently push the threaded area at the bottom onto the plastic nut.
4. Rotate the plastic nut anti-clockwise (viewed from the top). Ensure the plastic nuts are tightened evenly on twin pumps.
5. Fully tighten by hand.
6. Fit the sealing washer and hand tighten the pressure vessel (Fig. 3). Care must be taken when fitting the pressure vessel not to cross-thread on assembly.

**Do not overtighten the pressure vessel.**



Cont ...

# 1 READ BEFORE COMMENCING PUMP INSTALLATION

## A. Water storage capacity.

- 1.11 The hot and cold water storage capacity must be sufficient to meet the flow rates required by the pumped equipment and any other water using fittings and appliances, which may be operated simultaneously.
- 1.12 Ensure the pump is primed as described in the priming section before starting, damage to the shaft seal will result otherwise. See Section 5 - Commissioning.

## B. Water temperature

The water entering the pump must be controlled as follows:

- 1.13 The maximum allowable water temperature is 65 °C.
- 1.14 The minimum allowable water temperature is 4 °C.
- 1.15 **DO NOT** fit a pump if the hot water is heated via a method whereby the water temperature cannot be controlled, such as solar or solid fuel you must consult the PumpAssist team on +44 (0) 844 98 000 97.

## C. Pipework - General

- 1.16 **Secure pipework:** Ensure pipework to and from pump is independently supported & clipped to prevent forces being transferred to inlet and outlet branches of pump.
- 1.17 **Flux:** Solder joints must be completed and flux residues removed prior to pump installation (**flux damage will void any warranty**).
- 1.18 **Pipework design:** Care should be taken in the design of pipework runs to minimize the risk of air locks e.g. use drawn bends rather than 90° bends.



- 1.19 **DO NOT** introduce solder flux to flexible hoses, pumps or pump parts manufactured from plastic.

- 1.20 **DO NOT** allow contact with oil or cellulose based paints, paint thinners or strippers, acid based descalents or aggressive cleaning agents.



- 1.21 **DO NOT** install a non-return valve, or devices which contain non-return valves, in the suction (inlet) pipework to the pump. The pump must be free to vent to the supply tank at all times.

- 1.22 **DO NOT** bend the flexible hoses beyond 30°. They must be installed as straight as possible.

- 1.23 **DO NOT** connect this pump to the mains supply or fit in an unvented system.

## D. Plumbing & Electrical Installation Regulations

- 1.24 The plumbing installation must comply with “The Water Supply (Water Fittings) Regulations 1999” and “BS 6700” building regulations.
- 1.25 The plumbing installation must be installed by a qualified person.
- 1.26 The electrical installation must be carried out in accordance with the current national electrical regulations.
- 1.27 The electrical installation must be installed by a qualified person.

## E. Pressure vessel

- 1.27 Pressure vessel is charged at the factory see Section 6 - Maintenance for details.

Cont ...


## 2 LOCATION - GENERAL



- 2.11 **Access:** For emergencies and maintenance the pump must be easily accessible.
- 2.12 **Protection:** The pump must be located in a dry position, frost free and protected from freezing, particularly when installed in a loft (not recommended).
- 2.13 **Ventilation:** Ensure an adequate air flow to cool the pump. Separate the pump from other appliances that generate heat. An 80 mm (3 ") air gap must be maintained around the pump.
- 2.14 **Safety:** The motor casing can become very hot under normal operating conditions. Care must be taken to ensure it cannot be touched during operation.
- 2.15 **Water retention:** If possible site the pump in a location where in the unlikely event of a water leak, any spillage is contained or routed to avoid electrics or areas sensitive to water damage.
- 2.16 **Static inlet pressure:** Before deciding where to position the unit, check to ensure the static inlet head of water above the pump (Figs. 4 & 5), does not exceed the maximum permitted limits.
- 2.17 **Ambient temperature:** The pump must be sited in a location where the maximum ambient temperature does not exceed 40 °C.
- 2.18 **Pipework:** For optimum performance pipework **MUST** be 22 mm. Pipework should only reduce to 15 mm when entering terminal fitting.
- 2.19 **Static outlet pressure:** The static outlet head must also be within the maximum requirement, see Figs. 4 & 5.
- 2.20 **Noise:** If supplied the anti-vibration mounting feet and flexible hoses can be used to reduce noise transmission, however care must be taken when mounting the pump that any noise is not amplified through loose panels or pipework.  
**Do not screw down the pump.**
- 2.21 **Flexible hoses:** Use only Stuart Turner supplied hoses.
- 2.22 **Isolating valves:** Separate system isolating valves (non restrictive) must be fitted to allow easy pump service.
- 2.23 **Preferred pump location:** The pump must, for optimum performance, be sited as close as possible to and never more than 4 metres from the HOT WATER cylinder. The pump should always be sited **BELOW** the HOT WATER take-off from the cylinder. This will ensure the pump has access to an air free water supply which is important for trouble free operation (Figs. 4 & 5).  
The pump location is also dependent on limitations of the static inlet and outlet heads of the installation. For guidance on limitations and recommended location, consult the following relevant section for water installation.  
Either end of the pump is suitable for hot or cold water.


Cont ...

## 2 LOCATION - SINGLE PUMP




- 2.24 **The cold water supply: Must be a DEDICATED AIR FREE** supply via a tank connector, and must be positioned at a slightly lower level (25 mm minimum) than the feed pipe to the hot water cylinder.  
**Do not connect to the mains.**

## 2 LOCATION - TWIN PUMP




Negative Duty Twin Pump System  
Fig. 5

- 2.25 **Hot water cylinder or storage tank:** When a hot water cylinder or storage tank is used, ensure the pipework size from the cold water storage to the hot water storage is of adequate size and a minimum of 22 mm.
- 2.26 **Hot water supply:** The pump **must be** supplied with a **dedicated feed** direct from the hot water cylinder or storage tank, ensuring an air free connection to the pump. We recommend the use of either the side entry Stuart flange (SE) Part No 27900 or the top entry Stuart flange (TE) Part No 27800 see Fig. 6.
- 2.27 **Expansion pipe:** When the method of connection is to be made via the expansion pipe, the cold water storage cistern should be at least 1 metre above the top of the hot water cylinder.



G 1 Stuart flange  
top entry (TE) (Part  
No. 27800) with  
22 mm pipework to  
pump.



Factory installed G  $\frac{3}{4}$   
secondary tapping with  
22 mm pipework to pump.  
or  
Side mounted Stuart  
flange side entry (SE) (Part  
No 27900) with 22 mm  
pipework to pump.

Fig. 6

Cont ...



### 3 PUMP CONNECTIONS



- **Do not use stainless steel, chrome or nickel plated pipe with the flexible hose push-in plumbing connections.**
- **Do not introduce solder flux into the joint or surrounding area as connectors will be attacked and may fail and void warranty. All solder joints should be completed and flux residues removed before final connection to push-in connections, on the flexible hose.**
- **Do not allow contact with oil or cellulose based paints, paint thinners or strippers, acid based descalents or aggressive cleaning agents.**
- **Never operate pump with inlet and/or outlet isolating valves in the closed position. Damage will occur!**

3.11 **Hose to pump:** Inlet - use hoses supplied with isolating valves built-in for the inlets, push home onto the pump connections to a depth of 33 mm ensuring the strainers are in place.

Outlet - use hoses supplied with no isolating valves and follow same process.

3.12 **Hose to pipework:**

1. These plastic push-in connectors, must only be connected with the following:
  - a) 22 mm diameter copper pipe to BS EN 1057 - R250 (half hard) - Table 3.
  - b) 22 mm plastic pipe to BS 7291 part 1 and part 2 (Table 1), or part 3 (Table 1) plus internal support sleeve\*.

\* The internal bore of the plastic pipe must be supported against collapse with the pipe manufacturers recommended support sleeve (pipe insert).

- c) Appropriate plumbing fittings that are compatible and will provide a water tight connection.

Ensure the pipe is free from all score marks and deformities in the area of the insertion depth (Fig. 7) and cut the pipe square removing all burrs and sharp edges to prevent damage to the sealing 'O'-ring.

2. Prior to inserting pipe into fitting mark the insertion depth on the wall of the pipe with a soft pencil at a distance of 33 mm from the end to be inserted.




Fig. 7

3. Check in the mouth of the fitting that 'O'-ring, nylon washer and collet are in position.




Fig. 9

4. Push pipe firmly into fitting, until pencil mark is level with the top of the collet and the pipe stop resistance is felt. Pull on pipe to check it is secure and correctly fitted.
5. To break the joint, push pipe firmly into fitting, hold collet down and gently remove pipe. If the system has been filled with water care should be taken to isolate pump and towels used to absorb spilled water.

**3.13 Typical Low Level Installation:** In certain installations it may be necessary to install a 90° bend on the inlet or outlet connections of the pump before the flexible hose to accommodate a low level installation. For this purpose use a 22 mm stem elbow (not supplied).




Fig. 9

**If you have any concern either about using push-in fittings or should the joint leak on final test isolate the water supplies and contact PumpAssist on +44 (0) 844 98 000 97.**

Cont ...

## 4 ELECTRICAL INSTALLATION / EARTHING



- 4.11 **Regulations:** The electrical installation must be carried out in accordance with the current national electrical regulations and installed by a qualified person.
- 4.12 **Safety:** In the interests of electrical safety a 30 mA residual current device (**R.C.D. not supplied**) should be installed in the supply circuit. This may be part of a consumer unit or a separate unit.
- 4.13 Before starting work on the electrical supply ensure power supply is isolated.
- 4.14 **DO NOT** allow the supply cord to contact hot surfaces, including the motor shell, pump body or pipework. The cord should be safely routed and secured by cable clips.
- 4.15 **Adjacent pipes:** Adjacent suction and delivery pipes should be fitted with earthing clamps in accordance with current regulations (Fig. 10).

Diagram of  
earth continuity  
connections




Fig. 10

- 4.16 **Earthing:** This appliance must be earthed via the supply cord, which must be correctly connected to the earth point located in the terminal box.
- 4.17 **Pipework:** Copper or metallic pipework must have supplementary earth bonding where the continuity has been broken by flexible hoses or plastic components.
- 4.18 **Additional earthing:** Certain installations may require additional earthing arrangements such as equipotential bonding. Reference should be made to the relevant regulations concerning this subject to ensure compliance.
- 4.19 **Connections:** The pump must be permanently connected to the fixed wiring of the mains supply using the factory fitted supply cord, via a double pole switched fused spur off the ring main and **NOT** connected to the boiler or the immersion heater circuits.
- 4.20 **Wiring of connection unit:**




**WARNING: This appliance must be earthed.**

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow: Earth      Blue: Neutral      Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your connection unit proceed as follows:

The wire which is coloured green and yellow must be connected to the terminal in the connection unit which is marked with the letter E or by the earth symbol:  or coloured green or green and yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

4.21 **Fuses:** The following fuse size should be used with the appropriate pump:

Model	Fuse Size (AMPS)
All models	5

## 5 COMMISSIONING



### 5.11 **System Flushing**

This pump incorporates push-in connectors and plastic components that must not come into contact with solder flux, acid-based descalents or aggressive cleaning agents. The pipework system should be flushed out prior to the pump being connected to ensure any contaminants/chemical residues and foreign bodies are removed from elsewhere in the system.

- 5.12 **Water Supply:** Always ensure that water storage capacity is adequate to meet the demand. Ensure the pump chamber is full of water before starting the pump. Failure to do this could result in seal damage. To ensure dry running does not occur the pump must be primed as described in priming section below.

**Do not run pump dry.**

### 5.13 **Priming/starting:**

- a) Ensure all outlets are closed, turn power supply 'on' - pump will start, pressurise the system then stop.
- b) Open the shower valve or terminal fitting and with shower head in its lowest position, switch on the power supply to the pump for 5/10 seconds and then switch off again. Allow a further 30 seconds of gravity flow before switching the pump on to run for 10 seconds. Repeat this cycling until all air is purged from the system.
- c) Any tap or control valve within the system when opened and closed will now turn the pump on/off. If this is confirmed to be the case, the system is now operating correctly.
- d) Carefully check pump and pipework for leaks whilst pump running and stationary before leaving the installation unattended.

- 5.14 **For Further Technical Support:** Phone the Stuart Turner PumpAssist team on +44 (0) 844 98 000 97. Our staff are trained to help and advise you over the phone.


## 6 MAINTENANCE



6.11 Turn off water supplies to the pump and release pressure by opening water outlets before attempting maintenance.

6.12 **Inlet Strainer:** The inlet strainers may require periodical cleaning. The frequency of this operation is dependent upon installation conditions. The strainer is located in the inlet assembly of the pump casing and is removed as follows:-

- a) Isolate pump electrically.
- b) Release all system pressure.
- c) Isolate hot and cold water supplies via the integral pump isolating valve located in the flexible hoses and release hoses by holding the collets connected to the pump on the inlet side (see Section 3 - Pump Connections).
- d) The strainer is now visible and can gently be prised out of the inlet connection. Clean thoroughly.
- e) Refit strainer.
- f) Re-connect flexible hoses (see Section 3 - Pump Connections).
- g) After maintenance is completed refer to Section 5 - Commissioning section for instructions on re-starting pump.



6.13 No other routine maintenance is required.

6.14 **Pressure Vessel:** Should ever the need arise for the vessel to have its air charge checked or replenished, it should be carried out as follows: -

- a) Isolate pump electrically.
- b) Isolate hot and cold water supplies via the integral pump isolating valve located in the flexible hoses (see Section 3 - Pump Connections).
- c) Release system water pressure by opening a system outlet (tap).

Cont ...

d) Check air charge at Schrader valve (Fig. 12) using a tyre pressure gauge.

Model	Vessel Pressure		
	kPa	bar	psi
All models	90	0.9	13




Fig. 12

- e) Replenish air charge if required by injecting air into the vessel via the Schrader valve using a car or bicycle pump, ensuring a system outlet valve (tap) remains open during this procedure to allow the vessel to exhaust any excess water.
- f) Close all system taps, open hot and cold inlet pump isolating valves, turn on electrical power.
- g) After maintenance is completed refer to Section 5 Commissioning for instructions on re-starting pump.

6.15 **Water scale:** As water is heated scale deposits are released in areas of hard water, scale can cause the mechanical seal to stick if left without use for long periods. The pump must be run for at least 5 minutes every four weeks to “exercise” all working parts. Run on cool water. See Section 7 - Technical Specification for note on water temperature. This particularly applies to guest bathrooms used infrequently.

#### 6.16 **Cleaners, Disinfectants and Descalents:**



Acid based descalents and aggressive cleaning agents must not come into contact with the pump. The pump must be removed from the system prior to the use of these products. The system should be flushed to remove all chemicals before the pump is re-connected. If in any doubt as to the suitability of the chemical solutions, please contact our PumpAssist helpline on +44 (0) 844 98 000 97.

Cont ...

## 7 TECHNICAL SPECIFICATION

Pump Model		U2.3 bar Twin 49080	U3.3 bar Twin 49081	U2.3 bar Single 49082	U3.3 bar Single 49083
General	Guarantee	3 years			
	WRAS approval	Compliant			
Features	Pump type	Centrifugal			
	Mechanical seal	Nitrile / Carbon / Silicon Carbide			
	Anti-vibration feet	✓	✓	✓	✓
	Inlet strainer(s)	✓	✓	✓	✓
	Flexible hoses	4	4	2	2
	Run on Timer	3 sec	3 sec	3 sec	3 sec
	Dry run protection	✓	✓	✓	✓
Performance	Maximum head (closed valve)	2.3 bar	3.3 bar	2.3 bar	3.3 bar
	Performance @ 9 l/min	1.9 bar	2.8 bar	1.7 bar	2.5 bar
	Performance @ 18 l/min	1.7 bar	2.6 bar	1.2 bar	1.8 bar
	Maximum flow	58 l/min	63 l/min	32 l/min	
	Maximum static inlet pressure	6 metres			
	Maximum static outlet pressure	6 metres			
	Maximum working pressure*	460 kPa (4.6 bar)			
	Maximum ambient air temperature	40 °C			
	Min / Max water temperature**	Min 4 °C / Max 65 °C			
	Flow switch sensitivity (approx)	1.0 l/min			
	Pressure vessel air pre-charge	0.9 bar (13 psi)			
Connections	Pump connections	22 mm male			
Flexible hoses	Connections	22 mm female x 22 mm push-in x 200 mm long, isolating valves on inlet hoses			
Motor	Type	Induction, auto-reset thermal trip			
	Duty rating	Intermittent, 30 mins on, 30 mins off @ 20 l/min***		Intermittent, 30 mins on, 30 mins off @ 20 l/min	
Electrical	Power supply / phase / frequency	230 V a.c. / 1 / 50 Hz			
	Current (full load)	2.4 Amps	3.6 Amps	1.2 Amps	1.8 Amps
	Power consumption	540 Watts	820 Watts	290 Watts	410 Watts
	Fuse rating	5 Amps			
	Power cable (pre-wired)	1.5 metres			
Physical	Enclosure protection	IPX2			
	Length	345 mm	415 mm	322 mm	345 mm
	Width	167 mm			
	Height (excluding hoses)	367 mm			
	Weight (including fittings)	7.8 Kg	10.2 Kg	6.4 Kg	7.1 Kg

Stuart Turner reserve the right to amend the specification in line with its policy of continuous development of its products.

**Note:** For information on other voltages/frequencies which are not shown, consult PumpAssist on +44 (0) 844 98 000 97.

**\*Note:** The maximum pressure that can be applied to the pump under any installation conditions.

Cont ...



**\*\*Note:** A stored water temperature of 60°C is considered sufficient to meet all normal requirements and will minimize deposition of scale in hard water areas.

**\*\*\*Note:** Both ends pumping up to 10 l/min.

**7.11 Noise:** The equivalent continuous A-weighted sound pressure level at a distance of 1 metre from the pump does not exceed 70 dB(A).

## 8 TROUBLE SHOOTING GUIDE

Symptoms	Probable Cause	Recommended Action
Pump will not start.	Electrical supply.  Pump Jammed.  Damaged pressure switch.  Recommended static inlet/outlet heads exceeded.  Internal motor thermotrip activated.	Check power supply. Check fuse (see fuse section). Check circuit breaker is set. Check wiring connections.  If motor 'Buzzes' switch off power and contact Stuart Turner.  Turn off power. Release system water pressure. Turn on power, pump should start. If NOT contact Stuart Turner.  Re-position pump (see pump location section).  Wait for thermotrip to auto-reset and check that duty point and run time is within specification (see technical specification).
Reduced/intermittent flow.	Incorrect or no anti-aeration flange fitted  Incorrect pipe sizes.  Blocked inlet filters.  Air in system.  Hot water temperature set too high.  Blocked shower head spray plate	Check that the installation complies with installation instructions.  Check for correct pipe sizing, see Page 6 - Section 2.18.  Clean inlet filters (see maintenance section).  Run system on full hot for several minutes. Check that vents are fitted as detailed in instructions.  Reduce cylinder stat setting to 60 °C max.  Clean in accordance with manufacturers instructions.
No hot water.	Air locked water feed.  Heat source not operating.  All hot water has been used.  Faulty thermostatic mixer valve.	Vent hot water pump of air. Check cold feed to hot water cylinder. Check water level in cold water tank and that all stopcocks and isolating valves are open.  Check boiler is switched 'on'. Check cylinder thermostat. Check immersion heater. Check cylinder contains hot water.  Check tank volume is adequate.  Consult makers instructions.
Pump runs on with outlets closed.  or Pump cycles (hunts) on/off frequently.	Leak in system.  Damaged reed switch, P.C.B or pressure switch.  Jammed flow switch.  Low pressure in pressure vessel.  Debris under non-return valve sealing face.	Check tap washers, w/c valve washers, pipe joints.  If pump continues to run, this indicates a closed circuit in either the flow switch reed, pressure switch or P.C.B. in the terminal box. Contact Stuart Turner.  Remove outlet hoses and check that flow switch sits in lowest position. Check float for free movement.  Check pressure in pressure vessel (see maintenance section).  Run at full flow to try and flush away debris or remove, clean or replace non-return valve.
Flexible hose leaks	Not fitted correctly.  Damaged 'O'-rings.	Check that the hose is pushed firmly onto the pump inlet/outlet connections and pipework.  Check copper pipe ends are cleanly cut and deburred.

- 8.11 **Environment Protection:** Your appliance contains valuable materials which can be recovered or recycled.  
At the end of the products' useful life, please leave it at an appropriate local civic waste collection point.

9 THE TECHFLO qt GUARANTEE

Congratulations on purchasing a Stuart Turner pump.

We are confident this pump will provide many years of trouble free service as all our products are manufactured to the very highest standard.

All Techflo qt pumps are guaranteed to be free from defects in materials or workmanship for 3 years from the date of purchase.

Within the guarantee period we will repair, free of charge, any defects in the pump resulting from faults in material or workmanship, repairing or exchanging the whole unit as we may reasonably decide.

Not covered by this guarantee: Damage arising from incorrect installation, improper use, unauthorised repair, normal wear and tear and defects which have a negligible effect on the value or operation of the pump.

Reasonable evidence must be supplied that the product has been purchased within the guarantee term prior to the date of claim (such as proof of purchase or the pump serial number).

This guarantee is in addition to your statutory rights as a consumer. If you are in any doubt as to these rights, please contact your local Trading Standards Department.

In the event of a claim please telephone **‘PumpAssist’** or return the pump with the accessories removed e.g pipes etc. If you have any doubt about removing a pump, please consult a professional.

**+44 (0) 844 98 000 97**

Proof of purchase should accompany the returned unit to avoid delay in investigation and dealing with your claim.

You should obtain appropriate insurance cover for any loss or damage which is not covered by Stuart Turner Ltd in this provision.

Please record here for your records.

TYPE NO.	SERIAL NO.	DATE PURCHASED

## **Installers – Register with Stuart Turner and move up to Approved Installer status**

We receive thousands of enquiries every month from people seeking a Stuart Turner installer and by registering your details with us, we can offer consumers the opportunity to quickly locate an installer in their area.

Registration is free - simply click on the **‘register as an installer’** link on our homepage at **[www.stuart-turner.co.uk](http://www.stuart-turner.co.uk)** and complete a short form which will enable visitors to find your contact details on our web site ‘installer finder’. Alternatively use your smartphone to scan this QR code and go straight to the form.



We'll do the rest!

In addition we will ensure you receive advance notice on all new product launches and access to any special offers or promotions.

Following initial registration, Stuart Turner offers a professional training programme, enabling you to achieve Approved Installer status and opening the door to a range of additional benefits.

Contact [approvedinstaller@stuart-turner.co.uk](mailto:approvedinstaller@stuart-turner.co.uk) for further details.

## NOTES

## NOTES



## DECLARATION OF CONFORMITY

**2006/42/EC**

BS EN ISO 12100-1, BS EN ISO 12100-2, BS EN 809

**2006/95/EC**

BS EN 60335-1, BS EN 60335-2-41

**2004/108/EC**

BS EN 55014-1, BS EN 55014-2, BS EN 55022, BS EN 61000-3-2, BS EN 61000-3-3,  
BS EN 61000-4-2, BS EN 61000-4-3, BS EN 61000-4-4, BS EN 61000-4-5, BS EN 61000-4-6,  
BS EN 61000-4-11

**1999/519/EC**

BS EN 62233

**2011/65/EU**

IT IS HEREBY CERTIFIED THAT THE STUART ELECTRIC MOTOR DRIVEN PUMP AS SERIAL  
NUMBER BELOW, COMPLIES WITH THE ESSENTIAL REQUIREMENTS OF THE ABOVE E.E.C.  
DIRECTIVES.

\_\_\_\_\_

( \_\_\_\_\_ )

( \_\_\_\_\_ )

\_\_\_\_\_

RESPONSIBLE PERSON  
AND MANUFACTURER

STUART TURNER LIMITED  
HENLEY-ON-THAMES, OXFORDSHIRE  
RG9 2AD ENGLAND.

Signed. ....

Business Development Director

Stuart Turner are an approved company to BS EN ISO 9001:2000



Stuart Turner Ltd, Henley-on-Thames, Oxfordshire RG9 2AD ENGLAND

Tel: +44 (0) 1491 572655, Fax: +44 (0) 1491 573704

info@stpumps.co.uk www.stuart-turner.co.uk